Installation Manual



Components list



Pre-installation

TOOLS REQUIRED



HARDWARE INCLUDED

A  Ø10(x5) ST4.8x50(x5) (x1)	B  (x1)	C  (x2)		
D (x5)	E  (x2)	F  (x2) M6x12(x4)	G  (x1)	H  (x1)
I  (x2)	J  (x1)	K  (x1) ST4.2x35(x2)  Ø8 (x2)	(x1)	(x1)

Fixed at wall





Installation





Installation

4

C



(x2)



5





Installation

6

E



(x2)



7

F



(x2)

M6x12(x4)





Installation

8



9

K



(x1)



ST4.2x35(x2)



Ø8 (x2)



Installation

10





11





12





Installation

13





14

I



(x2)



Installation

15

B



(x1)



16

G



(x1)

H



(x1)



Installation

17

J



(x1)